# Part List, Mechanical

Applicable for R250s PRO

**Contents**

**1 Exploded View ..... 2**
1.1 R250s PRO ..... 2
**2 Part List ..... 3**
2.1 R250s PRO ..... 3
**3 Revision History ..... 4**

# 1 Exploded View

## 1.1 R250s PRO



# 2 Part List

## 2.1 R250s PRO

| Pos. | Description | Part Number | Comments |
|---|---|---|---|
| 1 | Antenna unit | KRE 101 1787/1 | |
| 2 | External antenna cover | SXA 104 6861 | |
| 3 | Front cover, orange | SXK 107 7191 | Incl. Loudspeaker, Speaker lever and Keyboard. |
| 3 | Front cover, green | SXK 107 7191/2 | Incl. Loudspeaker, Speaker lever and Keyboard. |
| 4 | Side snap dome connector | SXA 105 9671 | |
| 5 | Microphone boot | SXA 134 073 | |
| 6 | Microphone | RLC 122 103 | |
| 7 | LCD | RNH 942 40/22 | |
| 8 | LCD elastomeric | SXA 120 9463/2 | |
| 9 | Speaker contact pogo pin | SXA 104 7191 | |
| 10 | LCD light guide sub assembly | SXK 107 7671 | |
| 11 | Microphone elastomeric connector | SXA 120 4276 | |
| 12 | Microphone connector support | SXA 104 6862 | |
| 13 | Cable support foam | SXA 105 9668 | |
| 14 | System connector | RNV 899 07 | |
| 15 | Environmental seal | SXA 105 9691 | |
| 16 | Buzzer | KLJ 901 01 | |
| 17 | Buzzer boot | SXA 105 9757 | |
| 18 | Vibrator boot | SXA 105 9756 | |
| 19 | Vibrator | BKE 903 02 | |
| 20 | SIM holder | RNK 860 36/01 | |
| 21 | Sim card lid | SXA 105 9672 | |
| 22 | Screw battery | SXA 105 9759 | |
| 23 | Screw | SXA 134 226 | |
| 24 | Warranty seal | SVF 930 481/9 | |

# 3 Revision History

| Rev. | Date | Changes / Comments |
|---|---|---|
| D | 1999-11-24 | Convert from FrameMaker to Word<br>Item 25 Part no. changed |
| E | 2000-02-29 | Microphone boot Changed part number.<br>High gain antenna, System bus cover and Strap screw removed.<br>Pos. renumbered.<br>Document title and layout changed. |